



# XENOFLO

## INSTALLATION INSTRUCTIONS

Prior to installation: Make sure the lights have been off for a few minutes before beginning to install.  
**DO NOT TOUCH GLASS AT ANYTIME DURING INSTALLATION.**

- 1) Pop open the hood and give yourself ample lighting. You will need to see well into the areas around the light housing in order to do the installation properly a strong flash light is recommended.  
(You will notice that the area behind the xenon lamp in the engine bay is very crowded and leaves very little space for working properly. This may make installation tricky so take some time and patience to install. In some vehicles you may want to move some of the components directly behind the xenon lamp cover to give you better access if possible).
- 2) Remove the light housing back cover by pressing down on the top mounted tab and pulling away from the housing. Some vehicle will make it difficult to completely remove this cover unless you maneuver your way around the lamp socket. Do this with care not to damage it.
- 3) Rotate the socket counter-clockwise to remove it from the lamp.
- 4) Rotate the "sitting ring" the same way to loosen the bulb itself. Remove both from the light housing.
- 5) Take the new bulb and make sure the open tab on the bulb is pointing upward. You can match it's position to the light socket if you like to make sure it is pointing up. Put the "sitting ring" back on around the bulb. Make sure the words "TOP" are pointing upwards. If any of these positions are not correct the bulb will not lock in properly, when the ring is turned clockwise to secure bulb.
- 6) Reattach socket to bulb and reinstall cover over socket. This may be the trickiest part of the installation as the covers two bottom tabs must be perfectly seated before it can be locked into place.  
There may be wires in the way that must be moved aside to make this possible.  
(Some vehicles may have a different style of cover).



**DO NOT TOUCH GLASS BULB SURFACE!**

Check compatibility of product with vehicle manufacturer before installation. Bimmian or any of it's subsidiaries, employees, owners, operators, or sub-contractors will not be liable for your use or inability to use this product or any problems arising from your use of this product whether directly or indirectly caused by the use of this product.